

Platform scale with stainless steel display device KERN IXS



Platform scale with stainless steel display device with IP68 rating, XL-display und EC type approval [M] – now also as high resolution version with high-resolution display



Piece-counting function



Durable stainless steel weighing plate



Stainless steel display device with IP68 protection, hygienic and easy to clean

Platform scale with stainless steel display device KERN IXS



Features

- Tough industry standard suitable for use in harsh industrial applications
- **1** Platform: weighing plate stainless steel, painted steel base, silicone-coated aluminium load cell, protection against dust and water splashes IP65, Substruction in wing design, extremely resistant to bending
- Superior display size: digit height 55 mm, bright backlight for easy reading of weighing results, even in poor lighting conditions
- Display device: Stainless steel, protection against dust and water splashes IP68, integrated power supply
- ESD drain to protect against electrostatic discharge e.g. for electrostatically-charged weighing objects or people who work with the scale
- Thanks to interfaces such as RS-232, RS-485 and Bluetooth (optional) the scale can easily be connected to existing networks and facilitates the data exchange between the scale and printer

Technical data

- Large backlit LCD display, digit height 55 mm
- Weighing plate dimensions, stainless steel W×D×H
 - A** 300×240×86 mm
 - B** 400×300×89 mm, see larger picture
 - C** 500×400×123 mm
 - D** 650×500×133,5 mm
- Dimensions of display device W×D×H 232×150×80 mm
- Cable length of display device approx. 2,5 m
- Permissible ambient temperature -10 °C/40 °C

Accessories

- **3** Stand to elevate display device
 - A-D** Height of stand approx. 50 mm, KERN IXS-A01
 - A-D** Height of stand approx. 200 mm, KERN IXS-A02
 - B-D** Height of stand approx. 400 mm, KERN IXS-A03
 - C-D** Height of stand approx. 600 mm, KERN IXS-A04

- Internal rechargeable battery pack, operating time up to 80 h without backlight, charging time approx. 12 h, KERN GAB-A04
- Data interface RS-232, interface cable included, approx. 1,5 m, must be ordered at purchase, KERN KXS-A04
- Data interface RS-485, must be ordered at purchase, KERN KXS-A01
- **4** Bluetooth data interface for wireless data transfer to PC or tablets, must be ordered at purchase, not in combination with verification, KERN KXS-A02
- Foot switch, must be ordered at purchase, KERN KXS-A03
- Roller conveyor attachment, with smooth-running, hot-dip galvanised steel rollers with ball bearings, robust aluminium profile frame, KERN YRO-01
- Further details, plenty of further accessories and suitable printers see *Accessories*


STANDARD



OPTION



FACTORY



Model	Weighing range [Max] kg	Readability [d] g	Verification value [e] g	Minimal load [Min] g	Net weight approx. kg	Weighing plate	Option		
							Verification		DAkkS Calibr. Certificate
							MID KERN		DAkkS KERN
KERN IXS 6K-4	6	0,2	-	-	6	A	-	-	963-128
KERN IXS 10K-4	15	0,5	-	-	6	A	-	-	963-128
KERN IXS 10K-4L	15	0,5	-	-	11	B	-	-	963-128
KERN IXS 30K-3	30	1	-	-	11	B	-	-	963-128
KERN IXS 30K-3L	30	1	-	-	22	C	-	-	963-128
KERN IXS 60K-3	60	2	-	-	11	B	-	-	963-129
KERN IXS 60K-3L	60	2	-	-	22	C	-	-	963-129
KERN IXS 100K-3	150	5	-	-	22	C	-	-	963-129
KERN IXS 100K-3L	150	5	-	-	36	D	-	-	963-129
KERN IXS 300K-2	300	10	-	-	36	D	-	-	963-129
Dual-range balance switches automatically to the next largest weighing capacity [Max] and readability [d]									
KERN IXS 6K-3M	3 6	1 2	1 2	20 40	6	A	965-228	-	963-128
KERN IXS 10K-3M	6 15	2 5	2 5	40 100	6	A	965-228	-	963-128
KERN IXS 10K-3LM	6 15	2 5	2 5	40 100	11	B	965-228	-	963-128
KERN IXS 30K-2M	15 30	5 10	5 10	100 200	11	B	965-228	-	963-128
KERN IXS 30K-2LM	15 30	5 10	5 10	100 200	22	C	965-228	-	963-128
KERN IXS 60K-2M	30 60	10 20	10 20	200 400	11	B	965-229	-	963-129
KERN IXS 60K-2LM	30 60	10 20	10 20	200 400	22	C	965-229	-	963-129
KERN IXS 100K-2M	60 150	20 50	20 50	400 1000	22	C	965-229	-	963-129
KERN IXS 100K-2LM	60 150	20 50	20 50	400 1000	36	D	965-229	-	963-129
KERN IXS 300K-2M	150 300	50 100	50 100	1000 2000	36	D	965-229	-	963-129

Note: For applications that require verification, please order verification at the same time, initial verification at a later date is not possible. Verification at the factory, we need to know the full address of the location of use.

* Either RS-232 or RS-485 can be installed and used

Pictograms

<p>Internal adjusting: Quick setting up of the balance's accuracy with internal adjusting weight (motordriven)</p>	<p>KERN Communication Protocol (KCP): It is a standardized interface command set for KERN balances and other instruments, which allows retrieving and controlling all relevant parameters and functions of the device. KERN devices featuring KCP are thus easily integrated with computers, industrial controllers and other digital systems</p>	<p>Suspended weighing: Load support with hook on the underside of the balance</p>
<p>Adjusting program CAL: For quick setting up of the balance's accuracy. External adjusting weight required</p>	<p>GLP/ISO log: The balance displays serial number, user ID, weight, date and time, regardless of a printer connection</p>	<p>Battery operation: Ready for battery operation. The battery type is specified for each device</p>
<p>Easy Touch: Suitable for the connection, data transmission and control through PC, tablet or smartphone.</p>	<p>GLP/ISO log: With weight, date and time. Only with KERN printers</p>	<p>Rechargeable battery pack: Rechargeable set</p>
<p>Memory: Balance memory capacity, e.g. for article data, weighing data, tare weights, PLU etc.</p>	<p>GLP/ISO log: With weight, date and time. Only with KERN printers</p>	<p>Universal mains adapter: with universal input and optional input socket adapters for A) EU, CH, GB; B) EU, CH, GB, USA; C) EU, CH, GB, USA, AUS</p>
<p>Alibi memory: Secure, electronic archiving of weighing results, complying with the 2014/31/EU standard</p>	<p>Piece counting: Reference quantities selectable. Display can be switched from piece to weight</p>	<p>Mains adapter: 230V/50Hz in standard version for EU, CH. On request GB, USA or AUS version available</p>
<p>Data interface RS-232: To connect the balance to a printer, PC or network</p>	<p>Recipe level A: The weights of the recipe ingredients can be added together and the total weight of the recipe can be printed out</p>	<p>Power supply: Integrated in balance. 230V/50Hz standard EU. More standards e.g. GB, USA or AUS on request</p>
<p>RS-485 data interface: To connect the balance to a printer, PC or other peripherals. Suitable for data transfer over large distances. Network in bus topology is possible</p>	<p>Recipe level B: Internal memory for complete recipes with name and target value of the recipe ingredients. User guidance through display</p>	<p>Weighing principle: Strain gauges: Electrical resistor on an elastic deforming body</p>
<p>USB data interface: To connect the balance to a printer, PC or other peripherals</p>	<p>Totalising level A: The weights of similar items can be added together and the total can be printed out</p>	<p>Weighing principle: Tuning fork: A resonating body is electromagnetically excited, causing it to oscillate</p>
<p>Bluetooth* data interface: To transfer data from the balance to a printer, PC or other peripherals</p>	<p>Percentage determination: Determining the deviation in % from the target value (100 %)</p>	<p>Weighing principle: Electromagnetic force compensation: Coil inside a permanent magnet. For the most accurate weighings</p>
<p>WiFi data interface: To transfer data from the balance to a printer, PC or other peripherals</p>	<p>Weighing units: Can be switched to e.g. nonmetric units at the touch of a key. See balance model. Please refer to KERN's website for more details</p>	<p>Weighing principle: Single cell technology: Advanced version of the force compensation principle with the highest level of precision</p>
<p>Control outputs (optocoupler, digital I/O): To connect relays, signal lamps, valves, etc.</p>	<p>Weighing with tolerance range: (Checkweighing) Upper and lower limiting can be programmed individually, e.g. for sorting and dosing. The process is supported by an audible or visual signal, see the relevant model</p>	<p>Verification possible: The time required for verification is specified in the pictogram</p>
<p>Analogue interface: to connect a suitable peripheral device for analogue processing of the measurements</p>	<p>Hold function: (Animal weighing program) When the weighing conditions are unstable, a stable weight is calculated as an average value</p>	<p>DAKkS calibration possible (DKD): The time required for DAKkS calibration is shown in days in the pictogram</p>
<p>Interface for second balance: For direct connection of a second balance</p>	<p>Protection against dust and water splashes IPxx: The type of protection is shown in the pictogram</p>	<p>Factory calibration (ISO): The time required for Factory calibration is shown in days in the pictogram</p>
<p>Network interface: For connecting the scale to an Ethernet network</p>		<p>Package shipment: The time required for internal shipping preparations is shown in days in the pictogram</p>
		<p>Pallet shipment: The time required for internal shipping preparations is shown in days in the pictogram</p>

*The Bluetooth® word mark and logos are registered trademarks owned by Bluetooth SIG, Inc. and any use of such marks by KERN & SOHN GmbH is under license. Other trademarks and trade names are those of their respective owners.

KERN – Precision is our business

To ensure the high precision of your balance KERN offers you the the appropriate test weight in the international OIML error limit classes E1-M3 from 1 mg - 2500 kg. In combination with a DAKkS calibration certificate the best pre-requisite for proper balance calibration.

The KERN DAKkS calibration laboratory today is one of the most modern and best-equipped DAKkS calibration laboratories for balances, test weights and force-measurement in Europe.

Thanks to the high level of automation, we can carry out DAKkS calibration of balances, test weights and force-measuring devices 24 hours a day, 7 days a week.

Range of services:

- DAKkS calibration of balances with a maximum load of up to 50 t
- DAKkS calibration of weights in the range of 1 mg - 2500 kg
- Volume determination and measuring of magnetic susceptibility (magnetic characteristics) for test weights
- Database supported management of checking equipment and reminder service
- Calibration of force-measuring devices
- DAKkS calibration certificates in the following languages DE, EN, FR, IT, ES, NL, PL
- Conformity evaluation and reverification of balances and test weights

Your KERN specialist dealer: